



Type: ASD

1




- 1- ENTER DOOR WIDTH IN FEET OR INCHES ...
"36"
- 2- ENTER DISTANCE FROM REFERENCE POINT TO WALL OPENING ...
"24"
- 3- PICK REFERENCE POINT ...
- 4- PICK ON SAME FACE TO SET DIRECTION OF WALL OPENING ...
- 5- PICK OPPOSITE WALL FACE ...

2




PICK POINT CLOSE TO HINGE ...

3



ENTER DOOR TAG OR </> TO EXIT ...
"A123"


4



A123
3'-0"


Type: ADD

1



- 1- ENTER DOOR WIDTH IN FEET OR INCHES ...
"72"
- 2- ENTER DISTANCE FROM REFERENCE POINT TO WALL OPENING ...
"20"
- 3- PICK REFERENCE POINT ...
- 4- PICK ON SAME FACE TO SET DIRECTION OF WALL OPENING ...
- 5- PICK OPPOSITE WALL FACE ...

2




EQUAL SIZE LEAVES ? <Y or N> ...
"N"

ENTER SIZE FOR ACTIVE LEAF ...
"44"


PICK POINT CLOSE TO HINGE OF ACTIVE LEAF...

3



ENTER DOOR TAG OR </> TO EXIT ...
"B456"

4



B456
6'-0"

DTG-Imperial.fas

Door&Tag Generator
Automatic Single Door (ASD subroutine)
Imperial System - Tutorial

(C) ALVARO J. FERNANDEZ-VELASCO
ARCHITECT
e-mail: ajfv@arnet.com.ar

DTG-Imperial.fas

Door&Tag Generator
Automatic Double Door (ADD subroutine)
Imperial System - Tutorial

(C) ALVARO J. FERNANDEZ-VELASCO
ARCHITECT
e-mail: ajfv@arnet.com.ar